

1. If the screen is blank, press any button and this is usually the default screen (bottom line of screen displays “PW AutoRun VIEW” or “PW MAN SCN VIEW”)
2. Press “PW” (GREEN)
3. “0” is displayed in the top-right corner, change this number to “11” by pressing the (RED) button
4. Press “Pass” (GREEN)
5. Press “PAR” (RED) If screen displays something like “Scn running...” then press the GREEN button to go back and wait a few minutes for it to complete and repeat steps.
6. In this menu, “X” (WHITE) scrolls through a list of parameters while “-“ or ”+” (YELLOW, RED) alter those parameters.
7. Press “X” (WHITE) until “Link PC” is displayed.
  - While scrolling to “Link PC” many other parameters will be displayed. It is important that these parameters are NOT changed (pressing the RED or YELLOW button).
  - If you think you may have changed one on accident, press “OK” (GREEN) and then “NO” (GREEN). Then press “PAR” (RED) and try again.
8. When you reach “Link PC”, change the “No” to “Yes” by pressing the RED or YELLOW button.
9. Press “OK” (GREEN) then “YES” (RED)
10. Press “RTN” (GREEN) to return to the main menu