

1. From the main menu, press VIEW (Red)
2. Press BAT (white) this shows the internal battery voltage
3. Press (Red) this shows the wet sensor status
HH 0 (dry status)
HH 1 (wet status)
4. With a dry wet sensor, pour water over it to see if the status changes from (0) to (1)
5. if no change, try cleaning the wet sensor with a soft wet paper towel and try again